

EN



Product Warning & Instructions

Important: Instructions must be read before use by all users of the product.

Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your tent.

WARNING:

- Check your tent, pegs and any associated cordage is in good condition each time before use.
- Check for & avoid sharp items that could come into contact with the tent or cordage.
- Take care when walking past guy-lines. Trips could cause damage to the tent or injury.
- Always keep your tent a safe distance from flames or direct heat sources - do not cook inside the tent.

TIPS:

Setting up your tent tautly will avoid any excess movement from wind. Peg out the tent loosely at first, before moving round the tent and tightening the peg loops, trying to create equal tension on all sides.

PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- When packing: use different fold lines after packing 10 times, or stuff into sack.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause the material to weaken (UV degradation is excluded from warranty).
- Avoid using ridge-line or guy-line cord that is abrasive or rough as this can damage the attachment loops.
- Damage caused from trips or falls over guy-lines or ridge-lines is not covered by warranty

WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

DD Hammocks products are not suitable for children under 3.

CZ



Upozornění a pokyny k výrobku

Důležité: Všichni uživatelé výrobku si musí před použitím přečíst návod k použití.

Kempování je obecně velmi bezpečné, ale při používání našich výrobků vás žádáme, abyste dodržovali následující pokyny, které zajistí bezpečnost a zabrání poškození stanu.

VAROVÁNÍ:

- Před každým použitím zkontrolujte, zda jsou stan, kolíky a všechny související šňůry v dobrém stavu.
- Zkontrolujte, zda se ve stanu nebo na šňůře nenachází ostré předměty, které by se s nimi mohly dostat do kontaktu, a vyhněte se jim.
- Dávejte pozor, když procházíte kolem mužských linií. Zakopnutí by mohlo způsobit poškození stanu nebo zranění.
- Always keep your tent a safe distance from flames or direct heat sources - do not cook inside the tent.

TIPY:

Napnuté postavení stanu zabrání nadměrnému pohybu způsobenému větrem. Stan nejprve volně rozepněte, pak jej obejděte a utáhněte smyčky kolíků tak, abyste dosáhli stejného napětí na všech stranách.

PÉČE O VÝROBEK:

- Vlhký výrobek (výrobky) po použití vždy pověste a přirozeně vysušte.
- Skladujte na chladném, suchém a tmavém místě.
- Při balení: po zabalení 10x použijte různé skládací čáry nebo je nactěte do pytle.
- Použití při extrémních teplotách (nad 40 °C a pod -15 °C) se nedoporučuje.
- Dlouhodobé vystavení silnému UV záření může způsobit oslabení materiálu (degradace vlivem UV záření je vyloučena ze záruky).
- Nepoužívejte hřebenovou šňůru nebo šňůru na zavěšení, která je abrazivní nebo drsná, protože může dojít k poškození upevňovacích smyček.
- Záruka se nevztahuje na škody způsobené zakopnutím nebo pádem přes lana nebo hřebenová lana.

MYTÍ:

Pouze ručně v teplé (ne horké) vodě.
Neperte v pračce. Nesušte v sušičce.

Výrobky DD Hammocks nejsou vhodné pro děti do 3 let.