

EN



Product Warning & Instructions

Important: Instructions must be read before use by all users of the product.

Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your equipment.

WARNING:

- Check equipment is in good condition each time before use.
- Check for & avoid sharp items that could come into contact with the equipment.
- Do not overload the rucksack so much that balance is adversely affected or movement becomes difficult.
- Children should be supervised when using this product.
- Always keep your equipment a safe distance from flames or direct heat sources

PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause the material to weaken (UV degradation is excluded from warranty).

WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

DD Hammocks products are not suitable for children under 3.

DK



Produktadvarel og instruktioner

Vigtigt: Instruktionerne skal læses før brug af alle brugere af produktet.

Camping er generelt meget sikkert, men når du bruger vores produkter, beder vi dig om at overholde følgende for at garantere sikkerheden og undgå at beskadige dit udstyr.

ADVARSEL:

- Kontrollér, at udstyret er i god stand hver gang før brug.
- Tjek for og undgå skarpe genstande, der kan komme i kontakt med udstyret.
- Overbelast ikke rygsækken så meget, at det går ud over balancen eller bliver svært at bevæge sig.
- Børn skal være under opsyn, når de bruger dette produkt.
- Hold altid dit udstyr på sikker afstand af flammer eller direkte varmekilder.

PRODUKTPLEJE:

- Hæng altid fugtige produkter op efter brug og lad dem tørre naturligt.
- Opbevares på et køligt, tørt og mørkt sted.
- Brug i ekstreme temperaturer (over 40 °C og under -15 °C) anbefales ikke.
- Langvarig udsættelse for stærkt UV-lys kan få materialet til at svækkes (UV-nedbrydning er udelukket fra garantien).

VASKNING:

Må kun vaskes i hånden i varmt (ikke varmt) vand. Må ikke vaskes i maskine. Må ikke tørretumbles.

DD Hammocks produkter er ikke egnet til børn under 3 år.