

EN



Product Warning & Instructions

Important: Instructions must be read before use by all users of the product.

Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your tent.

WARNING:

- Check your tent, pegs and any associated cordage is in good condition each time before use.
- Check for & avoid sharp items that could come into contact with the tent or cordage.
- Take care when walking past guy-lines. Trips could cause damage to the tent or injury.
- Always keep your tent a safe distance from flames or direct heat sources - do not cook inside the tent.

TIPS:

Setting up your tent tautly will avoid any excess movement from wind. Peg out the tent loosely at first, before moving round the tent and tightening the peg loops, trying to create equal tension on all sides.

PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- When packing: use different fold lines after packing 10 times, or stuff into sack.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause the material to weaken (UV degradation is excluded from warranty).
- Avoid using ridge-line or guy-line cord that is abrasive or rough as this can damage the attachment loops.
- Damage caused from trips or falls over guy-lines or ridge-lines is not covered by warranty

WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

DD Hammocks products are not suitable for children under 3.

FI



Tuotteen varoitus ja ohjeet

Tärkeää: Kaikkien tuotteen käyttäjien on luettava ohjeet ennen käyttöä.

Telttailu on yleensä hyvin turvallista, mutta pyydämme sinua noudattamaan seuraavia ohjeita, jotta voit varmistaa turvallisuuden ja välttää teltan vahingoittumisen.

VAROITUS:

- Tarkista teltta, tapit ja mahdollinen köysi joka kerta ennen käyttöä, että ne ovat hyvässä kunnossa.
- Tarkista ja vältä teräviä esineitä, jotka voivat joutua kosketuksiin teltan tai narun kanssa.
- Ole varovainen kävellessäsi kaverilinjojen ohi. Kompastuminen voi vahingoittaa telttaa tai aiheuttaa loukkaantumisen.
- Pidä teltta aina turvallisen välimatkan päässä liekeistä tai suorista lämmönlähteistä - älä valmista ruokaa teltan sisällä.

VINKKEJÄ:

Kun teltta pystytetään tiukasti, vältetään tuulen aiheuttamat liikkeet. Kiinnitä teltta aluksi löysästi, ennen kuin kierrät teltan ympäri ja kiristät kiinnityssilmukat niin, että teltan kaikki sivut ovat yhtä kireällä.

TUOTTEEN HOITO:

- Ripusta kosteat tuotteet aina käytön jälkeen ja kuivaa luonnollisesti.
- Säilytä viileässä, kuivassa ja pimeässä paikassa.
- Kun pakkaat: käytä eri taittolinjoja pakkaamisen jälkeen 10 kertaa tai täytä säkkiin.
- Käyttöä äärimmäisissä lämpötiloissa (yli 40 °C ja alle -15 °C) ei suositella.
- Pitkäaikainen altistuminen voimakkaalle UV-valolle voi heikentää materiaalia (UV-vaurio ei kuulu takuun piiriin).
- Vältä käyttämästä hankaavaa tai karkeaa harjasiimaa tai köysiköyttä, sillä se voi vahingoittaa kiinnityslenkkejä.
- Takuu ei kata vaurioita, jotka johtuvat kompastumisista tai putoamisista köysiköysien tai harjalinjien yli.

PESU:

Käsin vain lämpimällä (ei kuumalla) vedellä. Älä pese koneessa. Älä kuivaa rumpukuivauksessa.

DD Hammocks -tuotteet eivät sovellu alle 3-vuotiaille lapsille.