

**EN**

## Product Warning & Instructions

**Important: Instructions must be read before use by all users of the product.**

**Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your tarp**

### **WARNING:**

- Check your tarp, pegs and any associated cordage is in good condition each time before use
- Check for & avoid sharp items that could come into contact with the tarp or cordage
- Take care when walking past guy-lines. Trips could cause damage to the tarp or injury
- Always keep your tarp a safe distance from flames or direct heat sources

### **TIPS:**

Keeping the tarp taut along the ridge-line will avoid any excessive movement causing premature wear on the material. Keeping tension by using a prussik knot or fastener on either side of the tarp can help to keep the tarp taut.

### **PRODUCT CARE:**

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- When packing: use different fold lines after packing 10 times, or stuff into sack.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause the material to weaken (UV degradation is excluded from warranty).
- Avoid using ridge-line or guy-line cord that is abrasive or rough as this can damage the attachment loops.
- Damage caused from trips or falls over guy-lines or ridge-lines is not covered by warranty

### **WASHING:**

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

**IT**

## Avvertenze e istruzioni sul prodotto

**Importante: le istruzioni devono essere lette prima dell'uso da tutti gli utenti del prodotto.**

**Il campeggio è generalmente molto sicuro, ma quando si utilizzano i nostri prodotti vi chiediamo di rispettare le seguenti indicazioni per garantire la sicurezza ed evitare di danneggiare il vostro telo**

### **ATTENZIONE:**

- Prima dell'uso, controllate ogni volta che il telo, i picchetti e le eventuali corde siano in buone condizioni.
- Controllare che non vi siano oggetti appuntiti che potrebbero entrare in contatto con il telo o la corda.
- Fare attenzione quando si passa accanto ai tiranti. Gli inciampi possono causare danni al telo o lesioni.
- Tenere sempre il telo a distanza di sicurezza da fiamme o fonti di calore dirette.

### **CONSIGLI:**

Mantenendo il telo teso lungo la linea di colmo si eviterà un movimento eccessivo che causerà un'usura prematura del materiale. La tensione può essere mantenuta utilizzando un nodo prussik o un dispositivo di fissaggio su entrambi i lati del telo.

### **CURA DEL PRODOTTO:**

- Appendere sempre i prodotti umidi dopo l'uso e farli asciugare naturalmente.
- Conservare in un luogo fresco, asciutto e buio.
- Per l'imballaggio: utilizzare diverse linee di piegatura dopo aver imballato 10 volte, oppure riporre in un sacco.
- Si sconsiglia l'uso a temperature estreme (superiori a 40 °C e inferiori a -15 °C).
- L'esposizione prolungata a forti raggi UV può causare l'indebolimento del materiale (la degradazione da raggi UV è esclusa dalla garanzia).
- Evitare l'uso di corde di colmo o di tiranti abrasivi o ruvidi per non danneggiare gli occhielli di fissaggio.
- I danni causati da inciampi o cadute su tiranti o linee di colmo non sono coperti da garanzia.

### **LAVAGGIO:**

Solo a mano in acqua calda (non bollente). Non lavare in lavatrice. Non asciugare in asciugatrice.