

EN



Product Warning & Instructions

Important: Instructions must be read before use by all users of the product.

Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your tent.

WARNING:

- Check your tent, pegs and any associated cordage is in good condition each time before use.
- Check for & avoid sharp items that could come into contact with the tent or cordage.
- Take care when walking past guy-lines. Trips could cause damage to the tent or injury.
- Always keep your tent a safe distance from flames or direct heat sources - do not cook inside the tent.

TIPS:

Setting up your tent tautly will avoid any excess movement from wind. Peg out the tent loosely at first, before moving round the tent and tightening the peg loops, trying to create equal tension on all sides.

PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- When packing: use different fold lines after packing 10 times, or stuff into sack.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause the material to weaken (UV degradation is excluded from warranty).
- Avoid using ridge-line or guy-line cord that is abrasive or rough as this can damage the attachment loops.
- Damage caused from trips or falls over guy-lines or ridge-lines is not covered by warranty

WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

DD Hammocks products are not suitable for children under 3.

NO



Produktadvarsel og instruksjoner

Viktig: Instruksjonene må leses før bruk av alle brukere av produktet.

Camping er generelt sett veldig trygt, men når du bruker produktene våre, ber vi deg om å overholde følgende for å ivareta sikkerheten og unngå å skade teltet ditt.

ADVARSEL:

- Kontroller at teltet, knaggene og eventuelt tauverk er i god stand hver gang før bruk.
- Se etter og unngå skarpe gjenstander som kan komme i kontakt med teltet eller tauverket.
- Vær forsiktig når du går forbi bardunene. Snubling kan føre til skader på teltet eller personskader.
- Hold alltid teltet på trygg avstand fra flammer eller direkte varmekilder - ikke lag mat inne i teltet.

TIPS:

Ved å sette opp teltet stramt unngår du at det beveger seg for mye på grunn av vind. Fest teltet løst først, før du beveger deg rundt teltet og strammer til knagglokkene, og prøv å skape lik spenning på alle sider.

PRODUKTPLEIE:

- Heng alltid opp fuktige produkter etter bruk og tørk dem på naturlig måte.
- Oppbevares på et kjølig, tørt og mørkt sted.
- Ved pakking: bruk forskjellige foldelinjer etter å ha pakket 10 ganger, eller stapp i sekk.
- Bruk i ekstreme temperaturer (over 40 °C og under -15 °C) anbefales ikke.
- Langvarig eksponering for sterkt UV-lys kan føre til at materialet svekkes (garantien omfatter ikke UV-skade).
- Unngå å bruke møne- eller bardunsnorer som er slitende eller ru, da dette kan skade festeløkkene.
- Skader forårsaket av snubling eller fall over barduner eller mønetråder dekkes ikke av garantien

VASKING:

Vask kun for hånd i varmt (ikke varmt) vann. Må ikke vaskes i maskin. Må ikke tørkes i tørketrommel.

DD Hammocks produkter er ikke egnet for barn under 3 år.