

EN



Product Warning & Instructions

Important: Instructions must be read before use by all users of the product.

Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your tarp

WARNING:

- Check your tarp, pegs and any associated cordage is in good condition each time before use
- Check for & avoid sharp items that could come into contact with the tarp or cordage
- Take care when walking past guy-lines. Trips could cause damage to the tarp or injury
- Always keep your tarp a safe distance from flames or direct heat sources

TIPS:

Keeping the tarp taut along the ridge-line will avoid any excessive movement causing premature wear on the material. Keeping tension by using a prussik knot or fastener on either side of the tarp can help to keep the tarp taut.

PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- When packing: use different fold lines after packing 10 times, or stuff into sack.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause the material to weaken (UV degradation is excluded from warranty).
- Avoid using ridge-line or guy-line cord that is abrasive or rough as this can damage the attachment loops.
- Damage caused from trips or falls over guy-lines or ridge-lines is not covered by warranty

WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

ES



Advertencias y instrucciones de uso:

Importante: Todos los usuarios deben leer detenidamente las instrucciones antes de usar el producto.

Camping est generalmente seguro, pero le pedimos que leer con lo siguiente para garantizar la seguridad:

ATENCIÓN:

- Antes de cada uso, compruebe que la lona, las estacas y el cordaje están en buen estado.
- Compruebe si hay objetos punzantes que puedan entrar en contacto con la tienda o la cuerda y evítelos.
- Tenga cuidado al pasar junto a los tensores. Los tropezos podrían causar daños a la lona o lesiones.
- Mantenga siempre la lona a una distancia segura de las llamas o de fuentes directas de calor: no cocine dentro de la lona.

CONSEJO:

Mantener la lona tensa a lo largo de la línea de cresta evitará cualquier movimiento excesivo que cause un desgaste prematuro del material. Mantener la lona tensa mediante un nudo prussik o un cierre a cada lado de la lona puede ayudar a mantener la lona tensa.

CUIDADO DEL PRODUCTO:

- Siempre cuelgue los productos húmedos después del uso y séquelos naturalmente.
- Guardar en un lugar fresco, seco y protegido de la luz.
- Es recomendable, tras haber doblado diez veces la producto, no hacerlo de igual manera antes de guardarla en la bolsa de transporte. Esto evitará roturas y el deterioro prematuro de la misma.
- No se recomienda el uso en temperaturas extremas (sobre 40°C o bajo -15°C).
- La exposición prolongada a la luz ultravioleta puede debilitar el material. (La degradación por ultravioletas está excluida de la garantía).
- Evite utilizar cuerdas abrasivas o ásperas, ya que podrían dañar los bucles de fijación.
- La garantía no cubre los daños causados por tropezos o caídas sobre vientos o líneas de caballete.

LAVADO:

Lave únicamente a mano con agua tibia (no caliente). No lavar a máquina. No usar secadora.

Los productos DD Hammocks no son adecuados para niños menores de 3 años.