

EN



Product Warning & Instructions

Important: Instructions must be read before use by all users of the product.

Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your tent.

WARNING:

- Check your tent, pegs and any associated cordage is in good condition each time before use.
- Check for & avoid sharp items that could come into contact with the tent or cordage.
- Take care when walking past guy-lines. Trips could cause damage to the tent or injury.
- Always keep your tent a safe distance from flames or direct heat sources - do not cook inside the tent.

TIPS:

Setting up your tent tautly will avoid any excess movement from wind. Peg out the tent loosely at first, before moving round the tent and tightening the peg loops, trying to create equal tension on all sides.

PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- When packing: use different fold lines after packing 10 times, or stuff into sack.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause the material to weaken (UV degradation is excluded from warranty).
- Avoid using ridge-line or guy-line cord that is abrasive or rough as this can damage the attachment loops.
- Damage caused from trips or falls over guy-lines or ridge-lines is not covered by warranty

WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

DD Hammocks products are not suitable for children under 3.

SE



Produktvarning och instruktioner

Viktigt: Instruktionerna måste läsas före användning av alla användare av produkten.

Camping är i allmänhet mycket säkert, men när du använder våra produkter ber vi dig att följa följande för att garantera säkerheten och undvika att skada ditt tält.

VARNING:

- Kontrollera varje gång före användning att tältet, tältpinnarna och eventuella tillhörande linor är i gott skick.
- Kontrollera om det finns vassa föremål som kan komma i kontakt med tältet eller linorna och undvik dem.
- Var försiktig när du går förbi staglinor. Om du snubblar kan det leda till skador på tältet eller personskador.
- Håll alltid tältet på säkert avstånd från lågor eller direkta värmekällor - laga inte mat inuti tältet.

TIPS:

Genom att sätta upp tältet spänt undviker du att det rör sig för mycket när det blåser. Sätt upp tältet löst först, innan du går runt tältet och drar åt pinnöglorna, försök att skapa samma spänning på alla sidor.

PRODUKTVÅRD:

- Häng alltid upp fuktiga produkter efter användning och låt dem torka naturligt.
- Förvara på en sval, torr och mörk plats.
- Vid packning: använd olika viklinjer efter att ha packat 10 gånger, eller stoppa i säck.
- Användning i extrema temperaturer (över 40 °C och under -15 °C) rekommenderas inte.
- Långvarig exponering för starkt UV-ljus kan göra att materialet försvagas (UV-försämring omfattas inte av garantin).
- Undvik att använda linor som är slipade eller skrovliga, eftersom det kan skada fästöglorna.
- Skador som orsakas av att du snubblar eller faller över staglinor eller åslinor täcks inte av garantin

TVÄTTNING:

Endast för hand i varmt (inte hett) vatten. Får inte tvättas i maskin. Får inte torktumlas.

DD Hammocks produkter är inte lämpliga för barn under 3 år.