

EN



Product Warning & Instructions

Important: Instructions must be read before use by all users of the product.

Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your tarp

WARNING:

- Check your tarp, pegs and any associated cordage is in good condition each time before use
- Check for & avoid sharp items that could come into contact with the tarp or cordage
- Take care when walking past guy-lines. Trips could cause damage to the tarp or injury
- Always keep your tarp a safe distance from flames or direct heat sources

TIPS:

Keeping the tarp taut along the ridge-line will avoid any excessive movement causing premature wear on the material. Keeping tension by using a prussik knot or fastener on either side of the tarp can help to keep the tarp taut.

PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- When packing: use different fold lines after packing 10 times, or stuff into sack.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause the material to weaken (UV degradation is excluded from warranty).
- Avoid using ridge-line or guy-line cord that is abrasive or rough as this can damage the attachment loops.
- Damage caused from trips or falls over guy-lines or ridge-lines is not covered by warranty

WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

DK



Produktadværel og instruktioner

Vigtigt: Instruktionerne skal læses før brug af alle brugere af produktet.

Camping er generelt meget sikkert, men når du bruger vores produkter, beder vi dig om at overholde følgende for at garantere sikkerheden og undgå at beskadige din tarp

ADVARSEL:

- Kontrollér, at din presenning, dine pløkker og eventuel tilhørende snor er i god stand hver gang før brug.
- Tjek for og undgå skarpe genstande, der kan komme i kontakt med presenningen eller snoren.
- Vær forsigtig, når du går forbi barduner. Snublen kan forårsage skade på presenningen eller personskaade.
- Hold altid din presenning på sikker afstand af flammer eller direkte varmekilder.

TIPS:

Ved at holde presenningen stram langs højderyggen undgår man, at den bevæger sig for meget og dermed slider på materialet for tidligt. Det kan hjælpe at holde presenningen stram ved at bruge en prussik-knude eller en fastgørelsesanordning på hver side af presenningen.

PRODUKTPLEJE:

- Hæng altid fugtige produkter op efter brug og lad dem tørre naturligt.
- Opbevares på et køligt, tørt og mørkt sted.
- Ved pakning: Brug forskellige foldelinjer efter at have pakket 10 gange, eller fyld i en sæk.
- Brug i ekstreme temperaturer (over 40 °C og under -15 °C) anbefales ikke.
- Langvarig udsættelse for stærkt UV-lys kan få materialet til at svækkes (UV-nedbrydning er udelukket fra garantien).
- Undgå at bruge ridge-line eller bardunline, der er slibende eller ru, da det kan beskadige fastgørelsesløkkerne.
- Skader forårsaget af snublen eller fald over barduner eller rygningslinjer er ikke dækket af garantien.

VASKNING:

Kun i hånden i varmt (ikke varmt) vand. Må ikke vaskes i maskine. Må ikke tørretumbles.