DD HAMMOCKS

EN ⚠ Product Warning & Instructions

Important: Instructions must be read before use by all users of the product.

Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your equipment.

WARNING:

- Check equipment is in good condition each time before use.
- Check for & avoid sharp items that could come into contact with the equipment.
- Children should be supervised when using this product.
- Always keep your equipment a safe distance from flames or direct heat sources
- DD Underblankets are not designed to be weight bearing. Do not use as a hammock.

PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolongued exposure to strong UV light can cause the material to weaken (UV degredation is excluded from warranty).

WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

DD Hammocks products are not suitable for children under 3.

DE ⚠ Produktwarnungen & Anweisungen

Wichtig: Die Anweisungen müssen von allen Benutzern des Produkts vor der Verwendung gelesen werden.

Camping ist im Allgemeinen sehr sicher, aber wenn Sie unsere Produkte benutzen, bitten wir Sie, Folgendes zu beachten, um die Sicherheit zu gewährleisten und Schäden an Ihrer Ausrüstung zu vermeiden.

WARNUNG:

- Prüfen Sie vor jedem Einsatz, ob die Ausrüstung in gutem Zustand ist.
- Suchen Sie nach scharfen Gegenständen, die mit dem Gerät in Berührung kommen könnten, und vermeiden Sie diese.
- Kinder sollten bei der Verwendung dieses Produkts beaufsichtigt werden.
- Halten Sie Ihre Ausrüstung immer in sicherer Entfernung von Flammen oder direkten Wärmequellen
- DD Unterbetten sind nicht dazu bestimmt, Gewicht zu tragen. Nicht als Hängematte verwenden.

PRODUKTPFLEGE:

- Hängen Sie feuchte Produkte nach dem Gebrauch immer auf und trocknen Sie sie natürlich.
- An einem kühlen, trockenen und dunklen Ort aufbewahren.
- Die Verwendung bei extremen Temperaturen (über 40 °C und unter -15 °C) wird nicht empfohlen.
- Bei längerer Einwirkung von starkem UV-Licht kann es zu einer Schwächung des Materials kommen (UV-Abbau ist von der Garantie ausgeschlossen).

WASCHEN

Nur mit der Hand in warmem (nicht heißem) Wasser waschen. Nicht in der Maschine waschen. Nicht im Trockner trocknen.

DD Hammocks Produkte sind nicht für Kinder unter 3 Jahren geeignet.