

EN



Product Warning & Instructions

Important: Instructions must be read before use by all users of the product.

Hammock camping is generally very safe, but we ask you to adhere to the following to ensure safety:

- Check your hammock & hammock suspension is in good condition each time before using it.
- Avoid contact with sharp or abrasive items during set-up and usage - either on your person or in the environment
- Do not set up your hammock above hard or sharp surfaces (e.g. rocks, sharp branches etc)
- We recommend a maximum height of 80cm/2.5ft above ground level (at the lowest point when in use)
- Check the area around the hammock is safe and secure including any overhanging branches
- Only use DD Hammocks' suspension with DD hammocks.
- DD hammocks are designed for single person use.
- Please always adhere to maximum weight limits.
- DD hammocks are unsuitable for children under 3.
- Keep away from fire.

WEIGHT LIMITS:

DD hammocks & DD Hammocks' suspension products are subject to weight limits.

Two-layered DD hammocks: the user should lie on top of both layers and the weight limit is 125kg.

Single-layered DD hammocks: The weight limit is 100Kg.

PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in cool, dry, dark place.
- When packing use different fold lines after packing 10 times or stuff into stuff sack.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause material to weaken (UV degradation is excluded from warranty).

WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

NO



Produktadvarsel og instruksjoner

Viktig: Alle brukere av produktet må lese bruksanvisningen før bruk.

Det er generelt sett veldig trygt å overnatte i hengekøye, men vi ber deg om å følge følgende regler for å ivareta sikkerheten:

- Kontroller at hengekøyen og hengekøyeoppheng er i god stand hver gang før du tar den i bruk
- Unngå kontakt med skarpe eller slipende gjenstander under oppsett og bruk - enten på deg selv eller i omgivelsene
- Ikke sett opp hengekøyen over harde eller skarpe overflater (f.eks. steiner, spisse greiner osv.)
- Vi anbefaler en maksimal høyde på 80 cm over bakkenivå (på det laveste punktet når den er i bruk)
- Kontroller at området rundt hengekøyen er trygt og sikkert inkludert eventuelle overhengende grener
- Bruk kun DD Hammocks oppheng med DD-hengekøyer
- DD-hengekøyer er beregnet for bruk av én person.
- Vennligst overhold alltid maksimale vektgrenser
- DD Hengekøyer er uegnet for barn under 3 år
- Holdes borte fra ild

WEIGHT LIMITS:

DD-hengekøyer og DD Hammocks Suspension-produkter er underlagt vektbegrensninger.

DD-hengekøyer med to lag: Brukeren skal ligge på toppen av begge lagene, og vektgrensen er 125 kg.

DD-hengekøyer med ett lag: Vektgrensen er 100 kg.

PRODUKTPLEIE:

- Heng alltid opp fuktige produkter etter bruk og tørk dem på naturlig måte.
- Oppbevares på et kjølig, mørkt og tørt sted
- Ved pakking: Bruk forskjellige foldelinjer etter å ha pakket 10 ganger eller stapp i stappesekk
- Bruk i ekstreme temperaturer (over 40 °C og under -15 °C) anbefales ikke.
- Langvarig eksponering for sterkt UV-lys kan føre til at materialet svekkes (garantien gjelder ikke for UV-forringelse)

VASKING:

Vask kun for hånd i varmt (ikke varmt) vann. Må ikke vaskes i maskin. Må ikke tørkes i tørketrommel.