

EN



Product Warning & Instructions

Important: Instructions must be read before use by all users of the product.

Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your equipment.

WARNING:

- Check equipment is in good condition each time before use.
- Check for & avoid sharp items that could come into contact with the equipment.
- Children should be supervised when using this product.
- Always keep your equipment a safe distance from flames or direct heat sources
- DD Underblankets are not designed to be weight bearing. Do not use as a hammock.

PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause the material to weaken (UV degradation is excluded from warranty).

WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

DD Hammocks products are not suitable for children under 3.

PL



Ostrzeżenia i instrukcje dotyczące produktu

Ważne: Instrukcje muszą zostać przeczytane przed użyciem przez wszystkich użytkowników produktu.

Kemping jest ogólnie bardzo bezpieczny, ale podczas korzystania z naszych produktów prosimy o przestrzeganie poniższych zasad, aby zapewnić bezpieczeństwo i uniknąć uszkodzenia sprzętu.

OSTRZEŻENIE:

- Przed każdym użyciem należy sprawdzić, czy sprzęt jest w dobrym stanie.
- Sprawdź i unikaj ostrych przedmiotów, które mogłyby wejść w kontakt z urządzeniem.
- Dzieci powinny być nadzorowane podczas korzystania z tego produktu.
- Zawsze trzymaj urządzenie w bezpiecznej odległości od płomieni lub bezpośrednich źródeł ciepła.
- DD Underblankets nie są przeznaczone do przenoszenia ciężaru. Nie należy ich używać jako hamaka.

PIELĘGNACJA PRODUKTU:

- Zawsze wieszaj wilgotne produkty po użyciu i susz naturalnie.
- Przechowywać w chłodnym, suchym i ciemnym miejscu.
- Nie zaleca się używania w ekstremalnych temperaturach (powyżej 40°C i poniżej -15°C).
- Długotrwała ekspozycja na silne promieniowanie UV może spowodować osłabienie materiału (degradacja UV nie jest objęta gwarancją).

MYCIE:

Prać ręcznie tylko w ciepłej (nie gorącej) wodzie. Nie prać w pralce. Nie suszyć w suszarce bębnowej.

Produkty DD Hammocks nie są odpowiednie dla dzieci poniżej 3 roku życia.