

EN



## Product Warning & Instructions

**Important: Instructions must be read before use by all users of the product.**

**Camping is generally very safe but when using our products we ask you to adhere to the following to ensure safety and avoid damaging your equipment.**

### WARNING:

- Check equipment is in good condition each time before use.
- Check for & avoid sharp items that could come into contact with the equipment.
- Children should be supervised when using this product.
- Always keep your equipment a safe distance from flames or direct heat sources
- DD Underblankets are not designed to be weight bearing. Do not use as a hammock.

### PRODUCT CARE:

- Always hang damp product(s) after use & dry naturally.
- Store in a cool, dry, dark place.
- Use in extreme temperatures (above 40 °C and below -15 °C) is not recommended.
- Prolonged exposure to strong UV light can cause the material to weaken (UV degradation is excluded from warranty).

### WASHING:

By hand only in warm (not hot) water. Do not machine wash. Do not tumble dry.

**DD Hammocks products are not suitable for children under 3.**

SE



## Produktvarning och instruktioner

**Viktigt: Instruktionerna måste läsas före användning av alla användare av produkten.**

**Camping är i allmänhet mycket säkert, men när du använder våra produkter ber vi dig att följa följande för att garantera säkerheten och undvika att skada din utrustning.**

### VARNING:

- Kontrollera att utrustningen är i gott skick varje gång före användning.
- Kontrollera om det finns vassa föremål som kan komma i kontakt med utrustningen och undvik dem.
- Barn bör hållas under uppsikt när de använder denna produkt.
- Håll alltid utrustningen på säkert avstånd från lågor eller direkta värmekällor
- DD Underlakan är inte utformade för att vara vikt bärande. Använd inte som hängmatta.

### PRODUKTVÅRD:

- Häng alltid upp fuktiga produkter efter användning och låt dem torka naturligt.
- Förvara på en sval, torr och mörk plats.
- Användning i extrema temperaturer (över 40 °C och under -15 °C) rekommenderas inte.
- Långvarig exponering för starkt UV-ljus kan göra att materialet försvagas (UV-försämring omfattas inte av garantin).

### TVÄTTNING:

Endast för hand i varmt (inte hett) vatten. Får inte tvättas i maskin. Får inte torktumlas.

**DD Hammocks produkter är inte lämpliga för barn under 3 år.**